

Chrome OS printing

16 September 2021 ver.2

Chrome OS compatibility

The following models supports you to print from Chrome OS. Printer compatibility information will be updated accordingly. The latest supporting models are listed below.

Color Multifunction Printers

ApeosPort series

ApeosPort-VII C7788	ApeosPort-V C6685	ApeosPort-IV C7780
ApeosPort-VII C7773	ApeosPort-V C6680 T2	ApeosPort-IV C6680
ApeosPort-VII C6688	ApeosPort-V C6680	ApeosPort-IV C5580
ApeosPort-VII C6673	ApeosPort-V C6676	ApeosPort-IV C5575
ApeosPort-VII C5588	ApeosPort-V C6675 T2	ApeosPort-IV C5570
ApeosPort-VII C5573	ApeosPort-V C6675	ApeosPort-IV C4475
ApeosPort-VII C4473	ApeosPort-V C5585	ApeosPort-IV C4470
ApeosPort-VII C4421	ApeosPort-V C5580 T2	ApeosPort-IV C3375
ApeosPort-VII C3373	ApeosPort-V C5580	ApeosPort-IV C3373
ApeosPort-VII C3372	ApeosPort-V C5576	ApeosPort-IV C3371
ApeosPort-VII C3321	ApeosPort-V C5575 T2	ApeosPort-IV C3370
ApeosPort-VII C2273	ApeosPort-V C5575	ApeosPort-IV C2275
ApeosPort-VI C7771	ApeosPort-V C4476	ApeosPort-IV C2270
ApeosPort-VI C6671	ApeosPort-V C4475 T2	ApeosPort C7070
ApeosPort-VI C5571	ApeosPort-V C4475	ApeosPort C6570
ApeosPort-VI C4471	ApeosPort-V C3376	ApeosPort C5570
ApeosPort-VI C3371	ApeosPort-V C3375 T2	ApeosPort C4570
ApeosPort-VI C3370	ApeosPort-V C3375	ApeosPort C3570
ApeosPort-VI C2271	ApeosPort-V C3374	ApeosPort C3070
ApeosPort-V C7785	ApeosPort-V C3373 T2	ApeosPort C3060
ApeosPort-V C7780 T2	ApeosPort-V C3373	ApeosPort C2560
ApeosPort-V C7780	ApeosPort-V C2276	ApeosPort C2060
ApeosPort-V C7776	ApeosPort-V C2275 T2	
ApeosPort-V C7775 T2	ApeosPort-V C2275	
ApeosPort-V C7775		

Color Multifunction Printers

DocuCentre series

DocuCentre-VII C7788	DocuCentre-V C6676	DocuCentre-IV C7780
DocuCentre-VII C7773	DocuCentre-V C6675 T2	DocuCentre-IV C6680
DocuCentre-VII C6688	DocuCentre-V C6675	DocuCentre-IV C5580
DocuCentre-VII C6673	DocuCentre-V C5580 T2	DocuCentre-IV C5575
DocuCentre-VII C5588	DocuCentre-V C5580	DocuCentre-IV C5570
DocuCentre-VII C5573	DocuCentre-V C5576	DocuCentre-IV C4475
DocuCentre-VII C4473	DocuCentre-V C5575 T2	DocuCentre-IV C4470
DocuCentre-VII C3373	DocuCentre-V C5575	DocuCentre-IV C3375
DocuCentre-VII C3372	DocuCentre-V C4476	DocuCentre-IV C3373
DocuCentre-VII C2273	DocuCentre-V C4475 T2	DocuCentre-IV C3371
DocuCentre-VI C7771	DocuCentre-V C4475	DocuCentre-IV C3370
DocuCentre-VI C6671	DocuCentre-V C3376	DocuCentre-IV C2275
DocuCentre-VI C5571	DocuCentre-V C3375 T2	DocuCentre-IV C2270
DocuCentre-VI C4471	DocuCentre-V C3375	DocuCentre-IV C2265N
DocuCentre-VI C3371	DocuCentre-V C3374	DocuCentre-IV C2265
DocuCentre-VI C3370	DocuCentre-V C3373 T2	DocuCentre-IV C2263N
DocuCentre-VI C2271	DocuCentre-V C3373	DocuCentre-IV C2263
DocuCentre-V C7780 T2	DocuCentre-V C2276	DocuCentre SC2022
DocuCentre-V C7780	DocuCentre-V C2275 T2	
DocuCentre-V C7776	DocuCentre-V C2275	
DocuCentre-V C7775 T2	DocuCentre-V C2265	
DocuCentre-V C7775	DocuCentre-V C2263	
DocuCentre-V C6680 T2		
DocuCentre-V C6680		

Color Printers

ApeosPort series

ApeosPort Print C5570

DocuPrint series

DocuPrint CP555 d	DocuPrint CM505 da	DocuPrint C5005 d
DocuPrint CP505 d	DocuPrint CM415 AP	DocuPrint C3555 d
DocuPrint CP475 AP	DocuPrint CM405 df	DocuPrint C2555 d
DocuPrint CP405 d	DocuPrint CM318 z	DocuPrint C2255
DocuPrint CP318 dw	DocuPrint CM315 z	
DocuPrint CP315 dw		

Monochrome Multifunction Printers

ApeosPort series

ApeosPort-VII 5021
ApeosPort-VII 4021
ApeosPort-V 7080
ApeosPort-V 6080
ApeosPort-V 5070
ApeosPort-V 4070
ApeosPort-V 4020
ApeosPort-V 3065
ApeosPort-V 3060
ApeosPort-V 2060

ApeosPort-IV 7080
ApeosPort-IV 6080
ApeosPort-IV 5070
ApeosPort-IV 4070
ApeosPort-IV 3070
ApeosPort-IV 3065
ApeosPort-IV 3060
ApeosPort-IV 2060

ApeosPort 5570
ApeosPort 4570
ApeosPort 3560
ApeosPort 3060
ApeosPort 2560

DocuCentre series

DocuCentre-V 7080
DocuCentre-V 6080
DocuCentre-V 5070
DocuCentre-V 4070
DocuCentre-V 3065
DocuCentre-V 3060
DocuCentre-V 2060

DocuCentre-IV 7080
DocuCentre-IV 6080
DocuCentre-IV 5070
DocuCentre-IV 4070
DocuCentre-IV 3065
DocuCentre-IV 3060
DocuCentre-IV 2060

DocuCentre-III C4100
DocuCentre-III C3100
DocuCentre-III 3007
DocuCentre-III 3000
DocuCentre-III 2007
DocuCentre-III 2000

Monochrome Printers

DocuPrint series

DocuPrint P508 d
DocuPrint P505 d
DocuPrint P455 d
DocuPrint P368 d
DocuPrint P365 d
DocuPrint P355 db
DocuPrint P355 d

DocuPrint M465 AP
DocuPrint M455 df
DocuPrint M355 df
DocuPrint 5105 d
DocuPrint 4408 d
DocuPrint 4405 d

DocuPrint 3508 d
DocuPrint 3505 d
DocuPrint 3208 d
DocuPrint 3205 d
DocuPrint 3105

Production Printers

B series

Fuji Xerox B9136
Fuji Xerox B9125
Fuji Xerox B9110
Fuji Xerox B9100

C series

Fuji Xerox D125
Fuji Xerox D110
Fuji Xerox D95
Fuji Xerox D136

Other models

FX4127
FX4112
PrimeLink C9065
PrimeLink C9070

Precautions

FUJIFILM Business Innovation Corp. will not support how to operate and set up on Chromebooks.

Charge print feature is not able to function under Chrome OS environment.

Problems that are likely to occur by printing from Chromebook

FUJIFILM Business Innovation Corp. shall not be held liable for defective printing and any other problems caused by printing from Chromebook.

The following events may occur by printing from Chromebook.

When the total printing number is odd during 2-side printing, the application may automatically insert a blank page as the last page depending on the OS setting. This is performed according to the specification of the application, and the printer counts the blank page as a sheet of printed page. This behavior cannot be avoided by configuring settings on the printer side.


Black & White documents may be printed in Color (process black) documents depending on the application. Changing the print settings from "Color" to "Black & White" allows you to print documents in pure black.

Print setting procedure


How to add printers using common Chrome OS is explained as follows:

Please note that FUJIFILM Business Innovation Corp. cannot support these operations to setting up on Chrome OS. If you have any questions, please consider to contact Google.


1. Open the setup menu from a menu bar at the bottom right of the screen.




2. Select "Advanced" from the menu on the left side of the settings.




3. Select "Printing" from "Advanced Settings", and then select "Printers" on the right side.




4. Selecting "Printers" displays a list of your networked printers (MFDs) under "Add Printer." Select "Save" or "Set up" on the right side of the printer you want to use. If it is not listed, go to Step 7.




5. If the printer (MFD) you selected supports Auto mode, it'll be registered to "Your saved printers", allowing you to select it from an application when printing. This completes the setting.




6. If it doesn't support Auto mode, go to Step 11.
7. If the printer (MFD) you want to use is not listed, select the icon on the right side of "Add Printer."




8. The screen to be added manually is displayed.




9. Enter the printer (MFD) name (arbitrary) and IP address, and then select Add.




10. If the printer (MFD) supports Auto mode, it'll be automatically registered to "Your saved printers", allowing you to select it from an application when printing. This completes the setting.




11. If the printer (MFD) doesn't support Auto mode, select a model from the list. If this is the case, install a PostScript option, as the printer (MFD) needs to support PostScript printing.




12. Select "Fuji Xerox" as a manufacturer.



13. Select the target printer (MFD) model from the list, and then select Add button.





14. The target printer (MFD) is registered to "Your saved printers", allowing you to select it from an application when printing. This completes the setting.

